

DIAGRAM 1.0





DIAGRAM 2.0



WELCOME:

STEP 1 – OPENING THE SAFE:

1. Install the 4 AA batteries in the Power Override Box. We recommend using high-quality batteries such as Duracell or Energizer.
2. Plug the Power Override Jack to the Power Override Hole.
3. Enter code. Factory default code is: 1-2-3-4
4. If the correct code is entered, the LCD Display will show "OPEN". If a wrong code was entered the LCD Display will show "E-CODE". Please re-enter the right code.
5. The door will automatically open and the display will show "OPENED" for 4 seconds.

NOTE: Remove the batteries from the Power Override Box and install them in the battery box that is located in the back of the safe door.

ENROLLING:

STEP 2 – CHANGING USER CODE:

1. Open the safe using the code.
2. Enter your new 4-Digit code and press the # key.

STEP 3 – CHANGING MASTER CODE:

1. Open the safe using the code.
2. Enter your existing master code. Factory default code is: 8-8-8-8-8-8
3. Press the # key. The LCD Display will show "NEU".
4. Enter your new 6-Digit master code and press the # key. The LCD Display will show "AGAIN".
5. Enter your new 6-Digit master code again and press the # key. If procedure is successful LCD Display will show "DONED", in case of a wrong code the LCD Display will show "E-CODE". Please repeat steps 2 thru 5.

EMERGENCY OPENING:

POWER OVERRIDE:

1. Open the safe by following STEP 1.

KEY OVERRIDE:

1. Gently unscrew the Keyhole Cover, this will reveal the Keyhole.
2. Insert the key and turn the key counter-clockwise (left) to open the safe.

Note: The safe keeps the code in memory up to 6 months without power.

TIPS:

- Use digits 1 – 0 to enter your code.
- Use the "RESET" key as backspace to clear the last digit.
- If you don't want your code showing on the LCD Display, before you enter your code press the "RESET" key twice followed by the # key. The LCD Display will show squares instead of digits.
- When the LCD Display shows "LO-BAT" it is highly recommended to change the batteries as soon as possible.



User Manual For Electronic safe

Models:

RAQ Keypad